



Canadian Model E Model AEP Model UK Model

AUTOMATIC STEREO TURNTABLE SYSTEM

#### **SPECIFICATIONS**

#### GENERAL

Power Requirements:

120 V ac, 60 Hz (Canadian model)

110, 120, 220, or 240 V ac adjustable, 50/60 Hz (E, AEP, UK model)

Power Consumption:

Dimensions: A

Approx.  $446 (w) \times 140 (h) \times 374 (d) mm$ 

 $17\frac{1}{2}$  (w) x  $5\frac{1}{2}$  (h) x  $14\frac{3}{4}$  (d) inches

Weight: Approx. 6.1 kg, 13 lb 7 oz (net)

6 W

Approx. 7.1 kg, 15 lb 10 oz (in shipping carton)

#### **TURNTABLE**

Platter:

32.6 cm (12 % inches) dia.

Aluminum-alloy diecast

Motor: DC servo-controlled motor (brushless and slotless)

Drive System: Direct drive

Speeds: 33½, 45 rpm

Pitch Control Range: ±4%

Wow and Flutter: 0.03 % (WRMS)

± 0.045 % (DIN)

S/N Ratio: 70 dB (DIN-B)

#### SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

#### TONEARM

Type:

Statically balanced, universal

Pivot-to-Stylus

to-Stylus Length:

216.5 mm, 8½ inches

Overall Arm Length:

300 mm, 113/4 inches

Overhang:

16.5 mm, <sup>21</sup>/<sub>32</sub> inches

Tracking Error: +3°, -1°

- .. -

Tracking-Force Adjustment Range:

0 – 3g 7.5 g

Shell Weight:

Cartridge Weight Range:

4 - 12 q

- Continued on next page -



#### CARTRIDGE (VL-32G) (E, AEP, UK model and Canadian model with cartridge)

Type: Moving magnet type

Frequency Range: 10 - 30,000 Hz

Channel Separation: 25 dB (1 kHz)

Output Voltage: 3 mV (1 kHz, 5 cm/sec, 45°)

Load Impedance: 50 kΩ

**Tracking Force:** 1.5 - 2.5 g (2 g recommended)

Stylus: Sony ND-134G

(Conical 0.5 mil diamond)

Weight: 5.5 g

#### MODEL IDENTIFICATIONS

- Specification Label -

#### Canadian model

SONY® STEREO TURNTABLE SYSTEM
MODEL NO. PS-11
AC 120V 60Hz 6W
SERIAL NO.
MADE IN

E, AEP, UK model

SONY®

STEREO TURNTABLE SYSTEM MODEL NO. PS-11


AC 110, 120, 220, 240 V~ 50/60Hz 6W

SERIAL NO.


BOAU

- Power Cord -

E model: euro-plug




E model: parallel blade plug



# SECTION 1 OUTLINE

#### 1-1. BLOCK DIAGRAM



#### 1-2. HALL MOTOR (TMD-21)

Adoption of the BSL (brushless and slotless) DC servo motor has the following major advantages.

- Very little noise due to the elimination of mechanical contacts, and current control by electronic switching.
- 2) Stable performance and very long operational life.

The operating principles of the Hall Motor (TMD-21) are described below.

#### Hall Element (VHE-510)

The magnetic field strength is converted into electrical signals by employing the Hall Effect \*.

\* The Hall Effect: When a current I flows through a substance, and a magnetic field B is applied at right angles to the direction of current flow, a potential difference V will be generated in a direction at right angles to both the current and magnetic field. (See Fig. 1-1.)




Fig. 1-1.


Note: There is no distinction between voltage and current terminals in the VHE-510 Hall Element.

#### **Motor Drive**

The TMD-21 Hall Motor employes the Hall Element to detect the position of magnets. When an N pole is positioned opposite the Hall Element H1 in Fig. 1-2, a positive voltage is generated in H1. This voltage is then amplified in IC1-3, and then applied to Q8 after passing through R31. Once Q8 is turned ON, B+ voltage is applied to L1. The current flowing through L1, and the magnet's magnetic field, produces a magnetic force and rotates the rotor in the direction of the arrow.

When the rotor rotates by 22°30', an S pol be positioned opposite the Hall Element H2 in 1-3, thus resulting in the generation of a nega voltage in H2. This voltage is amplified by I( passed through R36, thus turning Q11 ON, resulting in B- voltage being applied to L2. current flowing through L2, and the magnet's netic field, produce a magnetic force, again in same direction as before.

Therefore, N poles and S poles are repeat positioned opposite H1 and H2 Hall Elemrespectively every 45° of a rotation, resulting the generation of the voltages in H1, H2 which used to produce the force required to rotate rotor.









Fig. 1-3.




### DISASSEMBLY

#### 2-1. REMOVAL







## SECTION 3 ADJUSTMENTS

#### 3-1. MECHANICAL ADJUSTMENTS

#### Tonearm Height Adjustment

#### A). Automatic Return Operation

- 1. Bring the tonearm toward the inner of the record and put the stylus in the last groove of the record.
- 2. Slowly turn the turntable by hand to lift the tonearm.
- 3. Confirm that the clearance between the stylus tip and the record is 7 12 mm as shown in Fig. 3-1. If necessary, adjust the height of the arm lifter by loosening the set screw.
- 4. After the adjustment, confirm that the tonearm smoothly returns to the tonearm rest as shown in Fig. 3-2.





Fig. 3-2.

#### B). Manual Return Operation

- 1. Bring the tonearm to the desired position on the record.
- 2. Lift the cueing lever and confirm that the clearance between the stylus tip and the record is  $7-12 \, \text{mm}$  as shown in Fig. 3-1.


If necessary, bend the seesaw plate and adjust the height of the tonearm by turning the adjustment screw.





#### **Automatic Return Position Adjustment**

- 1. Perform the REJECT operation once.
- If the automatic return operation does not work properly, adjust by turning the adjustment screw as shown in Fig. 3-4.


Turning direction	Automatic return position		
0	slow		
2	fast		







#### Speed Detecting Head Position Adjustment



- 1. Remove the turntable platter.
- 2. Set the head deck as shown in Fig. 3-6.
- 3. Install the turntable platter.
- 4. Set the SPEED selector switch (S2) to 33 position.
- 5. Adjust the PITCH control (33) so that the stroboscope pattern appears stationary.
- 6. Confirm that the VTVM reads  $10-30\,\text{mV}$  ac. If necessary, adjust the position of the head deck by loosening the adjustment screw.

Note: Confirm that the head does not touch the turntable platter.





Fig. 3-6.



#### Tonearm Lever Position Adjustment

- 1. Secure the tonearm to the arm rest.
- 2. Set the drive gear to OFF position as shown in Fig. 3-7.
- 3. Install the tonearm lever as shown in Fig. 3-8.





Fig. 3-7.





#### 3-2. ELECTRICAL ADJUSTMENTS

#### Turntable Speed Adjustment

If correct speed cannot be obtained by adjusting the PITCH controls, adjust RV1.

- 1. Set the two PITCH control knobs (33 and 45) to the mechanical-mid position.
- 2. Set the SPEED selector switch to "33" or "45" position and adjust RV1 so that the stroboscope pattern appears stationary.





#### Motor Gain Adjustment

- 1. Turn the switch to H1 position and adjust RV2 for 2.3 V ac VTVM reading.
- 2. Turn the switch to H2 position and adjust RV3 for 2.3 V ac VTVM reading.


#### Offset Adjustment

Note: Offset means the unbalanced voltages of the hall element and IC.

When the offset voltage has changed, it causes the wow and flutter.

- Turn the switch to H1 position and adjust RV4 for 0 V dc VTVM reading or screen pattern of oscilloscope.
- Turn the switch to H2 position and adjust RV5 for 0 V dc VTVM reading or screen pattern of oscilloscope.

Oscilloscope screen pattern:



#### **DIAGRAMS**



- Conductor Side -

Replacement Semiconductors

For replacement, use semiconductors except in (

Q1-5, 7: 2SC634A





(2SC945)

Q6: 2SA678

(2SA733)





Q8, 10: 2SC1061

(2SC1419)





Q9, 11: 2SA671 (2SA755)



D1: S1RB10



D2, 3: EQB01-13 (EQA01-13R)




IC1: μPC324C





#### H1, 2: VHE-510

6.


Color code of sleeving over the end of the jacket.










- : part mounted on the conductor side.
- : B+ pattern
- : B- pattern
- Voltages are dc with respect to ground unless otherwise
- Readings are taken with a VOM (20  $k\Omega/V$ ). SPEED selector switch: 331/3 rpm.







AEP, UK, E MODEL









#### 4-2. SCHEMATIC DIAGRAM



## PS-11 PS-11



## PS-11 PS-11




#### Note:


- All capacitors are in μF unless otherwise noted. pF = μμF 50 WV or less are not indicated except for electrolytics.
- All resistors are in ohms,  $\frac{1}{2}$  W unless otherwise noted.  $k\Omega = 1000 \, \Omega$ ,  $M\Omega = 1000 \, k\Omega$
- \_\_\_\_\_: panel designation.
- \_\_\_\_\_: adjustment for repair.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken with a VOM (20 k $\Omega$ /V). SPEED selector switch: 33½ rpm.
- ----: B+ bus.
- ---: B- bus.
- Switch


Ref. No.	Switch	Position
S1	POWER	OFF
S2	SPEED	33½ rpm
S3	VOLTAGE SELECTOR (E, AEP, UK model)	

Note: The components identified by shading are critical for safety. Replace only with part number specified.

## EXPLODED VIEWS







## **ELECTRICAL PARTS LIST**

Note: Circled letters ( $\bigcirc$ A) to  $\bigcirc$ Z) are applicable to European models only.

Ref. No.	Part No. Descr	iption	Ref. No. Part No. Description
	SEMICONDUCTO	RS	C10 1-131-213-11 (B) 0.47 35 V tantalum
			C11 1-108-813-12 (B) 0.056 mylar
	Transistors		C12 1-108-810-12 ® 0.033 mylar
			C13, 14 1-121-415-11 (A) 100 16 V elect
> Q1 − 5	B 2SC63	4A	C15, 16 1-121-657-11 (B) 1000 25 V elect
• Q6	© 2SA67		
• Q7	B 2SC63		RESISTORS
Q8	(D) 2SC10		
Q9	(E) 2SA67	1	All resistors are in ohms. Common ¼W carbon resistors are
	• .		omitted. Check schematic diagram for values.
Q10	D 2SC106		
Q11	E). 2SA67	1	R41, 42 1-244-861-11 (A) 330 ½W
	10	•	1-244-897-11 (A) 10 to 16 W (F A FP LIK model)
	IC		R43 (1-244-899-11 12 k ½ W (Canadian model)
C1	(G) μPC324	4C	RV1 1-224-647-XX (B) 47 k, adjustable
			⇒ RV2, 3 1-224-644-XX (B) 4.7 k, adjustable
	Diodes		RV4, 5 1-224-644-XX (B) 4.7 k, adjustable
tristing komboning skips næ	ender a detemploje i Protoglavia o descriptionales a plane i in .	*0:1672A	1 22 / 0 / 1 ILL (S) 4. / K, adjustable
1	©SIRB10		RV101, 102 1-226-062-00 (B) 20 k, variable, PITCH
2, 3	B EQB01-	-13	9 20 11, 12 201
			SWITCHES
	Hall Device		THE PROPERTY OF THE PROPERTY O
1 2		_	S1 (1-516-889-00 D Micro, POWER (E, AEP, UK model)
11, 2	D VHE-51	.0	1-552-103-00 Micro, POWER (Canadian model)
	TRANSCORMERS		S2 1-552-123-00 (B) Lever Slide, SPEED
	TRANSFORMERS		S3 1-552-026-00 (E) Voltage Selector (E, AEP, UK model
	1-442-880-00 Power (	Canadian model)	MISCELLANEOUS
Γ1	1-442-901-00 D Power (1		MIOCELEAIVEOUS
			CNJ 1-509-547-00 © Connector, 3-p; AC IN
	CAPACITORS		(E, AEP, UK model)
			/1-102-222-21 (A) Capacitor, ceramic; 1000p 250 V
	s are in $\mu F$ and ceramic unle		CP1 (E, AEP, UK model)
	s are not indicated except fo	or electrolytics.	1-231-326-00 Encapsulated Component
$F = \mu \mu F$ , ele	ect = electrolytic		(Canadian model)
			F1, 2 1-532-387-00 (B) Fuse, 200 mAT (E, AEP, UK model)
1	_	25 V elect	NL1 1-519-135-11 © Lamp, neon
	1-102-110-11 (A) 220 p		1-534-985-XX Cord, power (Canadian model)
3	_	16 V elect	1-536-401-XX (A) Terminal Strip
4, 5		10 V elect	1-543-093-00 (E) Head, speed detecting
5	1-121-409-11 (A) 47	16 V elect	
,	1 102 114 11 🕜 172		1-549-073-00 (L) Cartridge, VL-32G (E, AEP, UK
	1-102-114-11 (A) 470 p		model and Canadian model with cartridge)
	1-108-811-12 B 0.039	mylar	
	O	35 V tantalum	1-549-074-00 (L) Stylus (ND-134G) (E, AEP, UK model and Canadian model with cartridge)
	andardization, interchangea		
	ibstituted for parts specified		1-551-294-21 <b>(E)</b> Cord, w/phono plug
	MXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX		1 561 012 11 D Composton band about

Note: The components identified by shading are critical for

1-561-013-11 E Connector, head shell

Note: Circled letters (  $\bigcirc$  to  $\bigcirc$  ) are applicable to European models only.

ACCESSORIES & PACKING MATERIALS					
Part No.	Description	Part No.	Description		
X-4844-012-0 including:	H Shell Head Ass'y	3-701-632-00	(A) Bag, plastic; accessary		
2-081-731-00	(A) Damper, shell head	3-701-634-00	(A) Bag, plastic; turntable platter		
X-2089-618-1	(A) Lead Wire Ass'y (red)	3-701-806-00	(A) Adaptor, 45 rpm		
X-2089-618-2	(A) Lead Wire Ass'y (green)	3-770-244-11	(E) Manual, instruction (E, AEP, UK model		
X-2089-618-3	(A) Lead Wire Ass'y (white)	3-770-244-31	Manual, instruction (Canadian model)		
X-2089-618-4	A Lead Wire Ass'y (blue)	3-793-395-11	(A) Gauge, overhang adjustment		
1-534-754-00	Cord, power; w/parallel blade plug (E model)	4-815-655-01	(A) Nut (A), cartridge		
1-534-819-00	G Cord, power (UK model)	4-838-319-01	A Screw (B), cartridge		
1-551-216-00	Cord, power; w/euro-plug (E model)	4-843-577-00	A Sheet, protection; dust cover		
The Strin Waled Cheer of Strategiese		4-847-314-00	© Bag, plastic; set		
2-054-619-00	A Spacer, cartridge	4-852-077-00	A Protector, counterweight		
2-054-624-01	Screw (B), cartridge (Canadian model without cartridge)	4-852-078-00	<ul><li>B Holder, turntable platter</li><li>B Cushion, upper</li></ul>		
		4-852-080-00 4-852-081-00	(B) Cushion, lower		
2-054-625-00	Screw (A), cartridge (Canadian model without cartridge)	4-852-095-00	Carton (E, AEP, UK model and Canadian model with cartridge)		
3-701-438-21	Washer, plastic; 2.5 mm dia (Canadian model without cartridge)	4-852-096-00	Carton (Canadian model without cartridge)		
3-701-613-00	(A) Bag, plastic; cartridge screws	4-852-204-00	(A) Spacer		
3-701-616-00	(A) Bag, plastic; counterweight		9		
3-701-623-00	(A) Bag, plastic; power cord (UK model)				

Note: The components identified by shading are critical for safety. Replace only with part number specified.